



ColorGATE

INNOVATIVE SOLUTIONS
COMMITTED TO COLOR

GETTING STARTED WITH COLORGATE VERSION 21

GUIDE FOR SINGLE HOST LICENSE / HARDWARE (SHL-HW)



Publisher

ColorGATE Digital Output Solutions GmbH
Grosse Duewelstrasse 1
30171 Hannover
Germany

Contact

Phone: +49 511 942 93-0
Fax: +49 511 942 93-40
E-mail: contact@colorgate.com
www.colorgate.com

The soft- and hardware names used in this manual are in most cases registered trademarks and are subject to legal rights. Information in this manual is subject to the patent protection rights. In this publication contained texts and images of the documented product is copyrighted material. All rights are reserved. Also rights for reproduction in photocopying, presentation, television, radio are reserved. A print-out of this manual is expressly permitted for ColorGATE sales partners and customers. Product names have been used here without a permission of an unrestricted usage. Images and texts have been arranged carefully. Nevertheless mistakes cannot be excluded completely. ColorGATE Digital Output Solutions GmbH is not responsible for incorrect information and its consequences. A legal responsibility or commitment is impossible.

ColorGATE Digital Output Solutions GmbH appreciates any feedback and suggestions for improving the documentation. Please send your comments by email to contact@colorgate.com.

© Copyright 2021 ColorGATE Digital Output Solutions GmbH

Updated 4/22/2021

Getting Started with ColorGATE

Thank you for purchasing our high-performance RIP software. This guide will lead you through the first steps with your ColorGATE product. It is viable for the following printing software products:




- ColorGATE Productionserver 21 (including Ceramic, Décor, Packaging and Textile Productionserver)
- ColorGATE Proofgate 21
- ColorGATE Filmgate 21

We wish you a lot of success working with our software.

Your ColorGATE team

About Our New Licensing Model

There are three different license types available for ColorGATE's version 21 software products:

-  **Single Host License / Software (SHL-SW):** Software-based license for use on a single computer. The software is activated with an activation code that binds the license to the respective computer via the ColorGATE license server. There are two ways to operate an SHL-SW license:
 - **Online mode:** A permanent internet connection is required (the software must connect to the license server in certain intervals, usually about once a day). The software can be transferred to another computer at any time.
 - **Offline mode:** An internet connection is only required during product activation. The software can then be operated offline. If you want to transfer your license to another computer later, you must contact our Customer Service team.
-  **Multi Host License / Software (MHL-SW):** Software-based license for use on multiple computers. MHL-SW licenses use an additional tool, the Floating License Manager (FLM), for license management via the local network.
-  **Single Host License / Hardware (SHL-HW):** Hardware-based license for use on a single computer. The license is verified by a USB dongle and a key file.

Note: Since version 20, this license type is no longer available in China.

Which license type do I have?

- If you received a **USB dongle**, you have a **Single Host License / Hardware (SHL-HW)**.
- If you **did not receive a USB dongle**, you have a **software-based license**.
 - If your license is intended for **use on a single computer**, you have a **Single Host License / Software (SHL-SW)**.
 - If your license is intended for use on **multiple computers**, or on a computer that has no internet access, but can access a server running our Floating License Manager over local network, you have a **Multi Host License / Software (MHL-SW)**.

This document covers the installation and activation with a **Single Host License / Hardware**. If you have acquired another license type, please refer to respective guides. You can download them from <https://www.colorgate.com/manuals>.

Upgrading to Version 21 From Version 20

If you are upgrading to version 21 from a version 20 installation, we recommend that you first install the latest version 20 build. You can download it from <https://support.colorgate.com> > **Download > Software & Updates > Version 20 > Productionserver/Filmgate/Proofgate 20** (Login required).

Then, perform a backup of your version 20 system configuration. You can find detailed instructions on how to do this on our [blog](#). After that, you can install version 21 and import your backup.

System Requirements

Operating systems (64-Bit)

- Microsoft Windows 8.1 (Pro, Enterprise)
- Microsoft Windows 10 (Pro, Enterprise)
- Microsoft Windows Server 2012
- Microsoft Windows Server 2016
- Microsoft Windows Server 2019
- (Apple macOS with Parallels Desktop)

Hardware

Minimum hardware requirements:

- CPU: Intel Core i3-2100 / Athlon II X2 340
- RAM: ≥ 4 GB
- Free disk space: 120 GB
- Display resolution: 1280 x 1024

Recommended for using one printer:

- CPU: Intel i5-7500 / AMD Ryzen 5 1600 or newer
- RAM: ≥ 8 GB
- Free disk space: 120 GB SSD
- Display resolution: 1920 x 1080

Recommended for using multiple printers:

- CPU: Intel i9-9900K / AMD Ryzen 7 3800X or newer
- RAM: ≥ 16 GB
- Free disk space: 512 GB NVME
- Display resolution: 1920 x 1080

Installation and operation

- LAN adapter, TCP/IP required for network connection
- USB port for the hardware dongle

Supported interfaces

Ethernet, TCP/IP, USB, FireWire

Use in virtualized environments

If the virtualization solution supports USB, ColorGATE software can usually be operated with hardware-based licenses. Please note, however, that ColorGATE cannot provide support for problems that occur in the context of the virtualization solution. There may be restrictions when printers, measuring devices or cutting plotters are connected via USB. In addition, the hardware requirements must be exclusively available as resources for the virtual machine to ensure a high-performance operation of the software. For these reasons, we recommend using virtualized environments for testing purposes only.

Registration


In order to use your software, you must create a user account in the Service & Support area of our website and register the product there. Afterwards, you will be able to activate it.

As long as you have not registered and activated your product, you will receive a request for product registration every time you start the program. Without product registration and activation, the program cannot be opened anymore after the trial period has expired.

As a registered user you also have access to the websupport system and the download area, where you can download software updates, MIM packages with ICC profiles and technical documentation for your software.

User Registration

1. Go to <https://support.colorgate.com>.
2. In the menu, select **Users & Products** > **User registration**.




3. An assistant will guide you through the next steps.

You can now register your product.

Product Registration

1. Go to <https://support.colorgate.com>.
2. If you are not logged in to your user profile, click **Login** to log in using your email address and password.
3. In the menu, select **Users & Products** > **Product registration**.




4. An assistant will guide you through the next steps.

We will now check your details and send you an email notification within the next two days that your permanent license file is available for download on the web server. This file will allow you to activate your product.

Installation

Prerequisite: Plug the dongle into a USB port before you start the installation. It must remain plugged-in to operate the program.

1. Download the software installer. You can find it on <https://support.colorgate.com> > **Download > Software & Updates** (Login required).
2. Open the Installer and follow the instructions.
3. In the **License Type Selection** step of the installation, select Single Host License / Hardware (SHL-HW). Click **Next** and follow the instructions to complete the installation.



4. For certain printers, you may need to install additional software components such as halftoning modules. You can find them on <https://support.colorgate.com> > **Download > Software & Updates > Printer-Related**.
5. If the printer is operated via USB: Install the printer driver provided by the manufacturer.


You have successfully installed the software

Activation


After you have completed the product registration, you must activate the software the first time you start the program by downloading the license file and coupling it with your dongle.

Online Activation

1. Start the software. A dialog opens that allows you to open the Keyupdate tool.
2. In Keyupdate, click **Download License File** to load the license file from the web server.



- Click **Update Attached Dongle** to couple the license file to the dongle.



The license file is now coupled to the dongle. The software can now be used without restrictions.


Offline activation

On a computer with internet access


- Go to <https://support.colorgate.com>.
- If you are not logged in to your user profile, click **Login** to log in using your email address and password.
- Go to your user profile and select the **Licenses** tab.
- Select the desired license number. In the **License details** section, click on **Download license file**.
- Transfer the license file to the RIP computer, e.g. with a USB drive or via local network.

On the RIP computer

6. Start the software. A dialog opens that allows you to open the Keyupdate tool.
7. In Keyupdate, click **Open License File** to open the license file from a local or network drive and save it from there.



8. Click **Update Attached Dongle** to couple the license file to the dongle.



The license file is now coupled to the dongle. The software can now be used without restrictions.

Support Options

Online Help

In the software, you can open the online help by pressing F1.

Value Pack

The Value Pack is a software maintenance and support contract available with all ColorGATE software solutions. It includes all updates and upgrades as well as access to technical support.

More information can be found at <https://www.colorgate.com/service-support/resources/value-packs>.

ColorGATE Sales Partner

Your dealer is your first point of contact for support requests.

Websupport

If your dealer is unable to help you, our websupport is at your disposal. Open <https://support.colorgate.com> and log in with your personal login credentials. Via **Service & Support** > **Websupport** you can create a websupport ticket.

Note: Please note that our websupport is only available with a valid ValuePack.